




Alarm Clock DVR Instructions: (CL-DVR)



Setup the DVR to Record:


Turn the DVR "ON" using the Remote Control. The Blue Light will turn ON and stay ON.




Note: When the unit is not recording, the blue light will be always ON.

Video Playback:

Use the USB port or use a Mini SD Card Reader to access its contents. If using the USB port, make sure the DVR is "ON" .






Blue Light ON




To Stop the Talking on Alarm Clock:

Press the "SET" button 3 times, until these icons flashes:



Then press "HR" until these icons  and  disappears:
After 8 sec, will hear a bip sound confirming the setting.



To Change the Time and Date:

Connect the Alarm Clock DVR into the computer using a USB cable. Turn the DVR ON using your remote control. Run the Application "Time_adjust_CLDVR.exe".

This window will show your device by the drive. When you see a letter in the "Devices:" box, Click on "UPDATE" and the DVR will automatically sync the Time and Date with your Computer. Your DVR Time and Date is updated.

