


Wireless Adapter Setup Instructions:

- 1- Open the File : RALINK. ZIP
- 2- Install the Software .
- 3- An icon will be added to your toolbar



- 4- Switch it to AP MODE :



- 5- Setup your SSID and WEP security in this page:



6- Open the "NETIP" Software to change the wireless IP address.

