

AU40B

Select the Camera:	1 to 255	[CAM] + [N] + [ENTER]
Set Preset Position:	1 to 128	[PRESET] + [N] + [ENTER]
Call Preset Position:	1 to 128	[CALL] + [N] + [ENTER]
Erase Preset Position:	1 to 128	[PRESET] + [N] + [OFF]
Set Auto Cruise:	1 to 6	[SHOT] + [N] + [ON]
Setting:		
Track=1 Sum=06		TELE {DOWN} / WIDE {DOWN}
POINT : [1 - 128] (PRESET POSITION)		
SPEED : [1 - 8] (SPEED OF THE CURRENT PRESET)		
TIME : [1 - 225] (DWELLING TIME OF THE CURRENT PRESET POINT)		
Run Auto Cruise:		[SHOT] + [N] + [Enter]
Stop Auto Cruise:	press off down until "clear tour" appears	[SHOT] + [N] + [OFF]
Auto Pan ON	to NEON and SAMSUNG protocols	[AUTO] + [P1] + [ON] + [P2] + [OFF]
Auto Pan ON (Pelco-D / Pelco-P)	Start Scan Position	[AUTO] + [ON]
	End Scan Position	[AUTO] + [OFF]
	Run Auto Pan	[AUTO] + [ENTER]
Stop Auto Pan		[AUTO] + [OFF]
Zoom Control:		[WIDE] / [TELE]
Focus Control:		[FAR] / [NEAR]
Iris Control:		[OPEN] / [CLOSE]
Camera Power:	ON	F1 + 0 + [ON]
	OFF	F1 + 0 + [OFF]
Back Light Compensation:	ON	F1 + 1 + [ON]
	OFF	F1 + 1 + [OFF]
Zero Illumination:	ON	F1 + 2 + [ON]
	OFF	F1 + 2 + [OFF]
Display:	ON	F1 + 3 + [ON]
	OFF	F1 + 3 + [OFF]
Digital Zoom:	ON	F1 + 4 + [ON]
	OFF	F1 + 4 + [OFF]
Keyboard Display Light:	ON	F1 + 5 + [ON]
	OFF	F1 + 5 + [OFF]

Focus:	Automatic	F1 + 6 + [ON]
	Manual	F1 + 6 + [OFF]
Iris:	Automatic	F1 + 7 + [ON]
	Manual	F1 + 7 + [OFF]
White Balance Mode:	Automatic	F1 + 8 + [ON]
	Manual	F1 + 8 + [OFF]
	Indoor Mode	F1 + 9 + [ON]
	Outdoor mode	F1 + 9 + [OFF]
	ATW Mode	F1 + 10 + [ON]
	One Push WB	F1 + 10 + [OFF]
Black & White / Color Switching:	ON	F1 + 11 + [ON]
	OFF	F1 + 11 + [OFF]
Auto Pan	< 180 , Low Speed	F1 + 12 + [ON]
	> 180 , Low Speed	F1 + 12 + [OFF]
Auto Pan	< 180 , Middle Speed	F1 + 13 + [ON]
	> 180 , Middle Speed	F1 + 13 + [OFF]
	< 180 , High Speed	F1 + 14 + [ON]
	> 180 , High Speed	F1 + 14 + [OFF]