

## ***CD66 Speed Dome Camera Setup:***

### **Set up and Call Preset**

- Set a preset [preset] + [N] + [ENTER]
- Call a preset [call] + [N] + [ENTER]

### **Auto Cruise**

- Programmable from 1~16 presets
- Start auto cruise [shot] + [1] + [enter]
- Stop auto cruise moving the joystick

### **Auto Pan**

START [AUTO] + N1 + [ON] + N2 [OFF]

N1= START POSITION

N2= END POSITION

PRESET + 17 + ENTER ( start position of auto pan )

PRESET + 18 + ENTER ( end position of auto pan )

CALL + 17 + ENTER ( auto tracking function )

CALL + 18 + ENTER ( auto panning )

PRESET + 20 + ENTER (close the digital zoom )

CALL + 20 + ENTER ( open the digital zoom )

**The dwell time for auto tracking is 4 sec between positions.**